

BSP 90° Adaptors

THREAD	Male Male 90° Swept	Male Male 90° Blocked	Male Female 90° Swept	Male Female 90° Blocked	Female Female 90° Swept	Female Female 90° Blocked
1/4" BSP	6369-04-04	6369-04-04B	6269-04-04	6269-04-04B	6169-04-04	-
3/8" BSP	6369-06-06	6369-06-06B	6269-06-06	6269-06-06B	6169-06-06	6169-06-06B
1/2" BSP	6369-08-08	6369-08-08B	6269-08-08	6269-08-08B	6169-08-08	6169-08-08B
5/8" BSP	6369-10-10	-	6269-10-10	-	6169-10-10	-
3/4" BSP	6369-12-12	-	6269-12-12	6269-12-12B	6169-12-12	6169-12-12B
1" BSP	6369-16-16	6369-16-16B	6269-16-16	6269-16-16B	6169-16-16	6169-16-16B
1 1/4" BSP	-	-	-	6269-20-20B	-	-
1 1/2" BSP	-	-	-	-	6169-24-24	-
2" BSP	-	-	-	6269-32-32B	-	-

BSP Cross & 'T' Pieces

THREAD	Male Cross	Male 'T'	Male Female Male 'T'	Female Male Male 'T'	Female 'T' Swivel	Female 'T' Fixed
1/8" BSP	-	TMMM-02	TMFM-02	-	-	4820-02
1/4" BSP	XMMMM04	TMMM-04	TMFM-04	TFMM-04	TFFF-04	4820-04
3/8" BSP	XMMMM06	TMMM-06	TMFM-06	TFMM-06	TFFF-06	4820-06
1/2" BSP	XMMMM08	TMMM-08	TMFM-08	TFMM-08	TFFF-08	4820-08
5/8" BSP	-	TMMM-10	-	TFMM-10	TFFF-10	-
3/4" BSP	XMMMM12	TMMM-12	TMFM-12	TFMM-12	TFFF-12	4820-12
1" BSP	-	TMMM-16	TMFM-16	TFMM-16	TFFF-16	-
1 1/4" BSP	-	-	-	-	TFFF-20	-

BSP Adjustable Adaptors

THREAD	Male Male 90° Adjustable	Male 'T' Lateral Adjustment	Male 'T' Central Adjustment
1/4" BSP	3900-04-04	-	-
3/8" BSP	3900-06-06	3600-06-06	3605-06-06
1/2" BSP	3900-08-08	-	-
3/4" BSP	3900-12-12	-	-
1" BSP	3900-16-16	-	-